

Vacuum Hose Sock Installation

How to install a slide-on vacuum hose sock.



1

Slide the cardboard tube over the end of the hose that connects to the wall inlet.



2

Without releasing any of the hose sock, push the cardboard tube to the control handle of the hose.



3

Pull a small amount of the hose sock off of the cardboard tube and onto the bottom of the control handle.

Tie the string on the hose sock over the bottom of the control handle of the hose.



4

Pull the cardboard tube toward the inlet end of the hose, gradually covering the hose with the hose sock.



5

Don't forget to include the electrical cord, if there is one.



6

The finished vacuum hose.